



Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Pieśe de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli

XX = AA, AD,









1 - B 961564 XX	26 - B 961346 NU
3 - B 964696 NU	27 - B 960604 XX
4 - B 961229 XX	29 - B 9467 XX
5 - B 961230 NU	30 - B 960976 XX
7 - B 961478 NU	31 - B 9421 XX
7a - B 961480 NU	32 - A 961640 NU
B961477NU-BC649..	33 - B 960018 XX
9 - B 960645 NU	33a - B 960286 XX
10 - B 960646 XX	34 - B 960024 NU
11 - A 960537 XX	34b - A 962728 NU
12 - B 961283 XX	35b - B 964585 XX
14 - B 960583 NU	36 - B 960883 XX
16 - B 961326 NU	36b - B 960828 XX
17 - B 961389 XX	37 - B 960486 XX
18 - B 961233 NU	38 - B 960167 XX
21 - A 963489 XX	39 - A 960944 NU

	P bar		MAX. 10		5			Q (3 bar)
	T °C		MAX. 80		65			l/min
					40			20
								13
								BC649..
								3,8



ALPHA

03.2025 / B665906



Ideal Standard International NV
Corporate Village – Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium
www.idealstandard.com

